



**Instruction includes methods of montage:**

1) Rod - conductive driven power supply, with an external power connector

2) Rod - non-conductive (drop lead)



**Tools needed for mounting:**


- drill
- pliers
- allen wrench
- soldering iron

**NOTE!** All LED strips must be connected to a 12 V or 24 V power supply.


**IMPORTANT:** The manual presents the simplest mounting procedure.  
More mounting procedures and related accessories can be found at [klusdesign.eu](http://klusdesign.eu)

\*If fully built fixtures are ordered and received from KLUS please skip to #4


**1.** Drill a holes with a diameter of 5 mm in the selected extrusion. 4 holes are needed to mount the fasteners and lead powering cables. Bevel the 2 holes for the fasteners so that the plastic screw head fits in.




**2.** Mount the fasteners to the extrusion. Manual for the DP-ZZ-PDS-O fastener can be downloaded from [www.klusdesign.eu](http://www.klusdesign.eu).




**3.** Mount the LED strip in the extrusion and lead the cables through pre-drilled smaller holes. Then lead them to the connector of the DP-ZZ-PDS-O fasteners. Each hole should lead a cable with one power pole, LED strip has to be cut before installation, so the wires can be easily routed to the holes.




**4.** Install the rod, cover and both end caps.



**5.** Install the W-KG-Z ceiling fasteners. The fastener installation manual can be downloaded at [www.klusdesign.eu](http://www.klusdesign.eu). Connect the cables, each for the single power pole to the fasteners. The cables should go through a pre-drilled hole just under the masking cover of the fastener.




**6.** Mount the fixture with rods into the ceiling fasteners. Mind that the power poles connected to the rods should match the ones connected to the fasteners.




\*If fully built fixtures are ordered and received from KLUS please skip to #4


**1.** Drill a holes with a diameter of 5 mm in the selected extrusion. 3 holes are needed to mount the fasteners and lead powering cable. Bevel the 2 holes for the fasteners so that the plastic screw head fits in.




**2.** Mount the fasteners to the extrusion. Manual for the DP-PDS-O fastener can be downloaded from [www.klusdesign.eu](http://www.klusdesign.eu).




**3.** Mount the LED strip in the extrusion and lead the cable through a pre-drilled hole.



**4.** Install the rod, cover and both end caps.



**5.** Install the W-KG ceiling fasteners. The fastener installation manual can be downloaded at [www.klusdesign.eu](http://www.klusdesign.eu). Place the power supplier next to the fastener and drill the ceiling to lead the cable to it.



**6.** Mount the fixture with rods into the ceiling fasteners. Connect the cable to the power supplier, leading it through a pre-drilled hole in the ceiling.

