


- 1. HR-MAX lighting fixture
- 2.1 Hermetic coupler (item 4.1)*
- 2.2 Hermetic coupler (item 4.2)*
- 2.3 Hermetic coupler (item 4.3)*
- 3.1 Connector (item 3.1)*
- 3.2 Connector (item 3.2)*
- 4. Cable for a 12 V / 24 V power supply** 5. HR-MAX-TW profile (Ref. C1828)***
- 6. HR-MAX-T profile (Ref. C1827)***
- 7. ZM Connector*
- 8. End cap*
- 9. End cap*


- 10. End cap*
- 11. End cap*
- 12. Screw*
- 13. Protective insert*
- 14. Mounting clip*
- *The full range of accessories and electronics is available at www.KlusDesign.eu
- **Use a cable with circular insulation and an outer diameter of not less than 6 mm / 0.24" and not more than 9 mm / 0.35".
- ***The total length of HR-MAX-TW and HR-MAX-T profiles should be 6 mm / 0.24" longer than the length of the HR-MAX fixture.


NOTE! The fixture comes with a Z-type fastener. A damaged external flexible conductor in this fixture cannot be replaced. In the event of damage to the external flexible conductor, the fixture must be disposed. The light source of this fixture is not replaceable; when the light source is worn out, the entire lighting fixture must be replaced.

IMPORTANT: Not all possible mounting procedures are presented here. More mounting procedures and related accessories can be found at www.KlusDesign.eu. Drawings of profiles and accessories in these instructions are simplified and only approximate the actual shapes.
















Remove the protective insert (13), by prying it out with a flat screwdriver.

Detach items (2.2, 2.3) of the hermetic coupler from item (2.1).



Lead the cable (4) through items (2.2, 2.3) of the hermetic coupler and attach it to the cable from the fixture, using both items (3.1, 3.2) of the connector.




Tighten all the items of the coupler.

NOTE! When placing the cables inside the coupler, make sure that the two items of the coupler (3.1, 3.2) do not touch each other.


NOTE! The items of the coupler should be tightened with a torque of 1.7 Nm.






Secure the surface of the fixture and the edges of the mounting track with protective tape.

Attach the mounting clips (14) to the HR-MAX fixture (1).



Insert the HR-MAX fixture together with the coupler and cable into the mounting track. The gland of the fixture and the coupler should be in the lower chamber of the HR-MAX-TW profile.

Mounting clips will protect the fixture against falling to the bottom of the mounting track before silicone is applied.





SERVICE

To disassemble the lighting fixture, use a knife to cut the layer of silicone between the wall of the fixture and the mounting track.



Using e.g. a flat screwdriver, pry up the fixture and remove it from the track.